

NOVACROWN

The Smart and Innovative Choice in Crown Moulding

FAQ

FAQ for NEW CONSTRUCTION installation

Q. At what stage of construction should NovaCrown be installed?

A. NovaCrown is best installed at drywall stage simultaneously with corner beading and taping. It blends seamlessly with the painting process.

Q. What do you use to cut NovaCrown?

A. We use a sharp fine-tooth 10" compound mitre saw

Q. What other tools do you recommend?

A. In addition to a compound mitre saw we recommend a compound mud applicator tube

FAQ for RETRO/RENO installation

Q. Should I paint NovaCrown before or after installation in a finished home?

A. For best results install our professionally pre-painted NovaCrown that has been sprayed using pre-catalyzed lacquer. If using unpainted NovaCrown then apply latex paint after installation.

Q. How does NovaCrown attach to the wall and ceiling?

A. NovaCrown is installed without any nails. Simply use Alex Plus to attach NovaCrown to the wall and ceiling. See our installation guide for more installation info.